



STORM 700x

DMX Profile Specification 1.1
Profiles 1-32
Firmware 1.0 and later

STORM 400x

DMX Profile Specification 1.1
Profiles 1-32
Firmware 1.5 and later

Table of Contents

Changelog	4
DMX Profile Overview for Aputure OS II	5
Control Channel Profiles	5
Detailed Breakdown of DMX Channels	5
No Effect Ranges	6
DMX Profiles with Motorized Accessories (XT52 Only)	6
DMX Profiles	7
Profile 1: CCT+ - 8-bit (3 ch.)	7
Profile 2: CCT+ - 16-bit (6 ch.)	7
Profile 3: CCT+ & Control - 8-bit (6 ch.)	8
Profile 4: CCT+ & Control - 16-bit (9 ch.)	9
Profile 5: CCT+ & FX & Control - 8-bit (11 ch.)	10
Profile 6: CCT+ & FX & Control - 16-bit (14 ch.)	12
Profile 7: xy - 8-bit (3 ch.)	14
Profile 8: xy - 16-bit (6 ch.)	14
Profile 9: xy & Control - 8-bit (6 ch.)	15
Profile 10: xy & Control - 16-bit (9 ch.)	16
Profile 11: xy & FX & Control - 8-bit (11 ch.)	17
Profile 12: xy & FX & Control - 16-bit (14 ch.)	19
Profile 13: CCT & xy - 8-bit (6 ch.)	21
Profile 14: CCT & xy - 16-bit (12 ch.)	21
Profile 15: CCT & xy & Control - 8-bit (9 ch.)	21
Profile 16: CCT & xy & Control - 16-bit (15 ch.)	23
Profile 17: Limited CCT & RGB - 8-bit (7 ch.)	24
Profile 18: Limited CCT & RGB - 16-bit (14 ch.)	25
Profile 19: Limited CCT & RGB & Control - 8-bit (10 ch.)	26
Profile 20: Limited CCT & RGB & Control - 16-bit (17 ch.)	27
Profile 21: Limited HSIC+ - 8-bit (5 ch.)	28
Profile 22: Limited HSIC+ - 16-bit (10 ch.)	28
Profile 23: Limited HSIC+ Control - 8-bit (8 ch.)	29
Profile 24: Limited HSIC+ Control - 16-bit (13 ch.)	30
Profile 25: RGB - 8-bit (3 ch.)	30
Profile 26: RGB - 16-bit (6 ch.)	31
Profile 27: RGB & Control - 8-bit (6 ch.)	31
Profile 28: RGB & Control - 16-bit (9 ch.)	32
Profile 29: RGBA - 8-bit (4 ch.)	33
Profile 30: RGBA - 16-bit (8 ch.)	33
Profile 31: RGBA & Control - 8-bit (7 ch.)	33
Profile 32: RGBA & Control - 16-bit (11 ch.)	34
CCT Quick Chart	35
DMX Control Channel Chart	36

DMX FX Parameters	38
FX Parameter: Paparazzi	38
FX Parameter: Fireworks	39
FX Parameter: Faulty bulb	40
FX Parameter: Lightning	41
FX Parameter: TV	42
FX Parameter: Pulsing	43
FX Parameter: Strobe	44
FX Parameter: Explosion	45
FX Parameter: Fire	46

Changelog

Release	Model	Change
December 2025	STORM 400x	• Added DMX Profiles 13 to 20 and 25 to 32. • Added Variable DMX Channel to the FX Profiles • Removed DMX Control Channel function: Enable DMX Controlled Fan

DMX Profile Overview for Aputure OS II

With the release of the Storm 1200X, Aputure is launching OS II. OS II features the same menu structure and experience and DMX Profile Structure between Aputure products.

Control Channel Profiles

Profiles labeled “+Control” include three extra channels (Strobe, Control and Fan). These profiles are ideal for users seeking advanced control methods.

OS II introduces DMX profiles with three additional control channels, depending on the product:

1. **Strobe Channel:** Enables strobing in any color.
2. **Control Channel:** Allows remote execution of light setting commands via a dedicated DMX channel.
3. **Fan Channel:** Adjusts the fan speed or behavior if the product is equipped with a fan.

Detailed Breakdown of DMX Channels

Strobe Channel:

The Strobe Channel enables strobe effects in any available color configuration, depending on the fixture's color mixing capabilities.

- **Example – Strobe a 10000K Color**

In **Profile 3**, set CCT (**Channel 2**) to 10,000K / 255. Set Strobe (**Channel 4**) to Rate of 25Hz / 255. The light will be at Max Strobe at 10,000K.

Control Channel:

The Control Channel allows remote execution of fixture settings via predefined DMX values. To apply a command, assign the specified value to the Control Channel for 2.5 seconds, then reset it to 0. The fixture will issue a brief confirmation flash (red) upon successful execution.

- **Example – Turning DMX Smoothing Off:**

In **Profile 3**, set Control Channel (**Channel 5**) to **Value 27** for 2.5 seconds, then reset it to 0. The fixture will flash red at 20% brightness to indicate that DMX Smoothing has been disabled.

- **Example – Turning DMX Smoothing On:**

In **Profile 3**, set Control Channel (**Channel 5**) to **Value 30** for 2.5 seconds, then reset it to 0. The fixture will flash red at 20% brightness to indicate that DMX Smoothing has been enabled.

Control Channel Signal Confirmation:

In cases where the confirmation flash is undesirable, such as when modifying multiple fixtures in enclosed spaces, the Signal Confirmation can be disabled by setting the Control Channel to **Value 15**, then back to 0. By default, the Signal Confirmation is enabled.

Fan Channel:

The Fan Channel allows direct control over fan speed and behavior via DMX. Set a constant value to maintain a specific fan state and modify the value as needed to adjust fan performance.

In the System settings, the Fan mode must be set to "DMX Controlled"

- **Example – Setting the fan to High:**

In **Profile 3**, set the Fan Channel (**Channel 6**) to **Value 45**. The fan channel must be saved at the value. When changing the value in a cue, it can be used to cut the fan during takes.

No Effect Ranges

In some DMX profiles, you may encounter a "No Effect" range at the beginning of a channel. This range is typically meant for slider boards, ensuring that when the slider is at 0, no effect is applied. These ranges should not be patched into lighting consoles, as they serve only to prevent unintended changes when the control is idle.

Channel	Function	Value	Percent	Description
X	±Green	0 - 255	0 - 100	-G to 0G to +G
		0 - 10	0 - 4	No Effect*
		11-20	5 - 8	Full Minus Green
		21 - 119	9 - 47	-99% - -1%
		120 - 145	48 - 57	0% Neutral
		146 - 244	58 - 96	1% - 99%
		245 - 255	97 - 100	Full Plus Green

DMX Profiles with Motorized Accessories (XT52 Only)

DMX Profiles 101–132 include support for the Motorized Fresnel. These profiles are functionally identical to DMX Profiles 1–32 but add additional DMX channels at the end of each profile to control the Motorized Fresnel. This structure ensures compatibility while providing extended control for fixtures equipped with motorized hardware.

DMX Profiles

Profile 1: CCT+ - 8-bit (3 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K - 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 137
		0 - 10	0 - 4	No Effect*	
		11 - 20	5 - 8	Full Minus Green	
		21 - 119	9 - 47	-99% - -1%	
		120 - 145	48 - 57	0% Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	Full Plus Green	

*Do not patch "No Effect" range into consoles

Profile 2: CCT+ - 16-bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K - 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 35390
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5 - 8	Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0% Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	Full Plus Green	

*Do not patch "No Effect" range into consoles

Profile 3: CCT+ & Control - 8-bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K - 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 137
		0 - 10	0 - 4	No Effect*	
		11 - 20	5 - 8	Full Minus Green	
		21 - 119	9 - 47	-99% - -1%	
		120 - 145	48 - 57	0% Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	Full Plus Green	
Control Channels					
4	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
5	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0% / Off
6	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 4: CCT+ & Control - 16-bit (9 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535 0 - 2621 2622 - 5243 5244 - 30146 30147 - 37355 37356 - 62914 62915 - 65535	0 - 100 0 - 4 5 - 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 35390
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
9	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 5: CCT+ & FX & Control - 8-bit (11 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K - 10000K	3200K / 24
3	±Green	0 - 255 0 - 10 11 - 20 21 - 119 120 - 145 146 - 244 245 - 255	0 - 100 0 - 4 5 - 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 137
FX					
4	Crossfade	0 - 255	0 - 100%	CCT to FX	0%
5	Trigger	0 - 9	0 - 4	Loop	0%
		10 - 69	5 - 27	Trigger / Run Once / Loop	
		70 - 255	28 - 100	Stop	
6	FX Selection	0 - 9	0 - 4	Paparazzi	0
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
		90 - 255	37 - 100	Reserved	
7	Frequency	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	

8	Variable	0 - 255	0 - 255		0
Control Channels					
9	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
10	Control Channel	0 - 255	0 -100	See Control Channel Chart	0 / Off
11	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 6: CCT+ & FX & Control - 16-bit (14 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 255	0 - 100	2500K - 10000K	3200K / 6117
5 / 6	±Green	0 - 65535 0 - 2621 2622 - 5243 5244 - 30146 30147 - 37355 37356 - 62914 62915 - 65535	0 - 100 0 - 4 5 - 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 35390
FX					
7	Crossfade	0 - 255	0 - 100%	CCT to FX	0%
8	Trigger	0 - 9	0 - 4	Loop	0%
		10 - 69	5 - 27	Trigger / Run Once / Loop	
		70 - 255	28 - 100	Stop	
9	FX Selection	0 - 9	0 - 4	Paparazzi	0
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
		90 - 255	37 - 100	Reserved	
10	Frequency	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	

11	Variable	0 - 255	0 - 100		0
Control Channels					
12	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
13	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0 / Off
14	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 7: xy - 8-bit (3 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.4234 / 136)
3	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.3989 / 125)

The xy range of the light is 0.1550y to 0.6815y and 0.3000x to 0.5500x. The Profile is created out of the 0 to 0.8 range.

Profile 8: xy - 16-bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.4234 / 34684)
5 / 6	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.3989 / 32686)

The xy range of the light is 0.1550y to 0.6815y and 0.3000x to 0.5500x. The Profile is created out of the 0 to 0.8 range.

Profile 9: xy & Control - 8-bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.4234 / 136)
3	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.3989 / 125)
Control Channels					
4	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
5	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0 / 0
6	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

Profile 10: xy & Control - 16-bit (9 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.4234 / 34684)
5 / 6	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.3989 / 32686)
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0 / 0
9	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

Profile 11: xy & FX & Control - 8-bit (11 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.4234 / 136)
3	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.3989 / 125)
FX					
4	Crossfade	0 - 255	0 - 100	CCT to FX	0%
5	Trigger	0 - 9	0 - 4	Loop	0%
		10 - 69	5 - 27	Trigger / Run Once / Loop	
		70 - 255	28 - 100	Stop	
6	FX Selection	0 - 9	0 - 4	Paparazzi	0%
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
		90 - 255	37 - 100	Reserved	
7	Frequency	0 - 19	0 - 7	1	0%
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
8	Variable	0 - 255	0 - 100		0
Control Channels					
9	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random	

				(0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
10	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0 / 0
11	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

Profile 12: xy & FX & Control - 16-bit (14 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.4234 / 34684)
5 / 6	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.3989 / 32686)
FX					
7	Crossfade	0 - 255	0 - 100	CCT to FX	0%
8	Trigger	0 - 9	0 - 4	Loop	0%
		10 - 69	5 - 27	Trigger / Run Once / Loop	
		70 - 255	28 - 100	Stop	
9	Effect Selection	0 - 9	0 - 4	Paparazzi	0%
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
		90 - 255	37 - 100	Reserved	
10	Frequency	0 - 19	0 - 7	1	0%
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
11	Variable	0 - 255	0 - 100		0%
Control Channels					
12	Strobe	0 - 13	0 - 5	Off	0% / Off

		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
13	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0% / Off
14	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / Auto
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

Profile 13: CCT & xy - 8-bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K - 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 137
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0-100	CCT to xy	0%
5	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.4234 / 136)
6	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.3989 / 125)

* Do not patch "No Effect" range into consoles

Profile 14: CCT & xy - 16-bit (12 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K - 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 35390
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7 / 8	Crossfade	0 - 65535	0-100	CCT to xy	0%
9 / 10	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.4234 / 34684)
11 / 12	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.3989 / 32686)

Profile 15: CCT & xy & Control - 8-bit (9 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K - 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 137
		0 - 10	0 - 4	No Effect*	
		11 - 20	5 - 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0-100	CCT to xy	0%
5	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.4234 / 136)
6	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.3989 / 125)
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0% / Off
9	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / Auto
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 16: CCT & xy & Control - 16-bit (15 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 35390
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7 / 8	Crossfade	0 - 65535	0-100	CCT to xy	0%
9 / 10	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.4232 / 34684)
11 / 12	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.3989 / 32686)
Control Channels					
13	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
14	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0% / Off
15	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / Auto
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 17: Limited CCT & RGB - 8-bit (7 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K - 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 137
		0 - 10	0 - 4	No Effect*	
		11 - 20	5 - 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0 - 100	CCT to RGB	0%
5	Red	0 - 255	0 - 100	Red Intensity	100% / 255
6	Green	0 - 255	0 - 100	Green Intensity	100% / 255
7	Blue	0 - 255	0 - 100	Blue Intensity	100% / 255

* Do not patch "No Effect" range into consoles

Profile 18: Limited CCT & RGB - 16-bit (14 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K - 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 35390
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5 - 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7 / 8	Crossfade	0 - 65535	0 - 100	CCT to RGB	0%
9 / 10	Red	0 - 65535	0 - 100	Red Intensity	100% / 65535
11 / 12	Green	0 - 65535	0 - 100	Green Intensity	100% / 65535
13 / 14	Blue	0 - 65535	0 - 100	Blue Intensity	100% / 65535

* Do not patch "No Effect" range into consoles

Profile 19: Limited CCT & RGB & Control - 8-bit (10 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K - 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 137
		0 - 10	0 - 4	No Effect*	
		11 - 20	5 - 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0 - 100	CCT to RGB	05
5	Red	0 - 255	0 - 100	Red Intensity	100% / 255
6	Green	0 - 255	0 - 100	Green Intensity	100% / 255
7	Blue	0 - 255	0 - 100	Blue Intensity	100% / 255
Control Channels					
8	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
9	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0%
10	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / Auto
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 20: Limited CCT & RGB & Control - 16-bit (17 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K - 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 35390
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5 - 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7 / 8	Crossfade	0 - 65535	0 - 100	CCT to RGB	0%
9 / 10	Red	0 - 65535	0 - 100	Red Intensity	100% / 65535
11 / 12	Green	0 - 65535	0 - 100	Green Intensity	100% / 65535
13 / 14	Blue	0 - 65535	0 - 100	Blue Intensity	100% / 65535
Control Channels					
15	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
16	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0%
17	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / Auto
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 21: Limited HSIC+ - 8-bit (5 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K - 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 137
		0 - 10	0 - 4	No Effect*	
		11 - 20	5 - 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Hue	0 - 255	0 to 359.9°	Degrees	0% / 0
5	Saturation	0 - 255	0 - 100%	White Light to RGB	0% / 0

* Do not patch "No Effect" range into consoles

Profile 22: Limited HSIC+ - 16-bit (10 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K - 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 35390
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5 - 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7 / 8	Hue	0 - 65535	0 to 359.9°	Degrees	0% / 0
9 / 10	Saturation	0 - 65535	0 - 100%	White Light to RGB	0% / 0

* Do not patch "No Effect" range into consoles

Profile 23: Limited HSIC+ Control - 8-bit (8 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K - 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 137
		0 - 10	0 - 4	No Effect*	
		11 - 20	5 - 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Hue	0 - 255	0 to 359.9°	Degrees	0° / 0
5	Saturation	0 - 255	0 - 100%	White Light to RGB	0% / 0
Control Channels					
6	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
7	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0%
8	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / Auto
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 24: Limited HSIC+ Control - 16-bit (13 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K - 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 35390
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5 - 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7 / 8	Hue	0 - 65535	0 to 359.9°	Degrees	0% / 0
9 / 10	Saturation	0 - 65535	0 - 100%	White Light to RGB	0% / 0
Control Channels					
11	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
12	Control Channel	0 - 255	0 - 100	See Control Channel Chart	0% / 0
13	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / Auto
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 25: RGB - 8-bit (3 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1	Red	0 - 255	0 - 100	Red Intensity	0% / 0
2	Green	0 - 255	0 - 100	Green Intensity	0% / 0
3	Blue	0 - 255	0 - 100	Blue Intensity	0% / 0

Profile 26: RGB - 16-bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1 / 2	Red	0 - 65535	0 - 100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0 - 100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0 - 100	Blue Intensity	0% / 0

Profile 27: RGB & Control - 8-bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1	Red	0 - 255	0 - 100	Red Intensity	0% / 0
2	Green	0 - 255	0 - 100	Green Intensity	0% / 0
3	Blue	0 - 255	0 - 100	Blue Intensity	0% / 0
Control Channels					
4	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
5	Control Channel	0 - 255	0 - 100	SEE CONTROL CHANNEL CHART	0%
6	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / Auto
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

Profile 28: RGB & Control - 16-bit (9 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1 / 2	Red	0 - 65535	0 - 100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0 - 100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0 - 100	Blue Intensity	0% / 0
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0-100	SEE CONTROL CHANNEL CHART	0% / 0
9	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / 0
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

Profile 29: RGBA - 8-bit (4 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Red	0 - 255	0 - 100	Red Intensity	0% / 0
2	Green	0 - 255	0 - 100	Green Intensity	0% / 0
3	Blue	0 - 255	0 - 100	Blue Intensity	0% / 0
4	Amber	0 - 255	0 - 100	Amber Intensity	0% / 0

Profile 30: RGBA - 16-bit (8 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Red	0 - 65535	0 - 100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0 - 100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0 - 100	Blue Intensity	0% / 0
7 / 8	Amber	0 - 65535	0 - 100	Amber Intensity	0% / 0

Profile 31: RGBA & Control - 8-bit (7 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Red	0 - 255	0 - 100	Red Intensity	0% / 0
2	Green	0 - 255	0 - 100	Green Intensity	0% / 0
3	Blue	0 - 255	0 - 100	Blue Intensity	0% / 0
4	Amber	0 - 255	0 - 100	Amber Intensity	0% / 0
Control Channels					
5	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
6	Control Channel	0 - 255	0 - 100	SEE CONTROL CHANNEL CHART	0% / 0
7	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / Auto
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

Profile 32: RGBA & Control - 16-bit (11 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Red	0 - 65535	0 - 100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0 - 100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0 - 100	Blue Intensity	0% / 0
7 / 8	Amber	0 - 65535	0 - 100	Amber Intensity	0% / 0
Control Channels					
9	Strobe	0 - 13	0 - 5	Off	0% / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
10	Control Channel	0 - 255	0 - 100	SEE CONTROL CHANNEL CHART	0% / 0
11	Fan Mode	0 - 38	0 - 15	Auto/Smart	0% / 0
		39 - 77	16 - 30	High	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75	Delayed #	
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

CCT Quick Chart

CCT	8-bit DMX Value	16-bit DMX Value
2500 K	0	0
3200 K	24	6117
3800 K	44	11360
4300 K	61	15729
4800 K	78	20098
5600 K	106	27088
6500 K	136	34952
7500 K	170	43690
9000 K	221	56797
10000 K	255	66535

DMX Control Channel Chart

The DMX Control Channel of the Profile should be a 0 value and then moved to the specific DMX Value to execute the command. Once executed, the DMX value should be returned to zero.

DMX			FUNCTION	DESCRIPTION	Time to Save
0	-	10	No function	No function	2.5 seconds
11	-	13	Signal Flash Enabled	When sending a Control Channel Command, the Light Flashes to confirm received	2.5 seconds
14	-	16	Signal Flash Disabled	When sending a Control Channel Command, the Light will not flash when a command is received.	2.5 seconds
17	-	19	Sidus BT On	Enable Sidus BT	2.5 seconds
20	-	22	Sidus BT Off	Disable Sidus BT	2.5 seconds
23	-	25	Sidus BT Reset	Reset Sidus BT	2.5 seconds
26	-	28	DMX Smoothing: Off	Snap to Intensities	2.5 seconds / Instant On
29	-	31	DMX Smoothing: Smooth	Smooth to Intensities	2.5 seconds / Instant On
32	-	34	DMX Smoothing: Super Smooth	Super Smooth to Intensities	2.5 seconds / Instant On
35	-	37	DMX Smoothing: Feather	Super Smooth from 0-4%, Snaps from 5 to 100%	2.5 seconds / Instant On
38	-	40	CRMX On	Turns wireless CRMX ON	2.5 seconds
41	-	43	CRMX Off	Turns wireless CRMX OFF	2.5 seconds
44	-	46	CRMX Unlink	TX: Unlink all linked fixtures RX: Unlink the fixture from a CRMX transmitter	2.5 seconds
47	-	49	CRMX Link	If set as a CRMX Transmitter, it will send the Link Signal	2.5 seconds

50	-	52	CRMX Mode RX	If set to a CRMX TX, it will change to RX. If it is off, it will remain off.	2.5 seconds
53	-	55	CRMX Mode TX	If set to a CRMX RX, it will change to TX. If it is off, it will remain off.	2.5 seconds
56	-	58	N/A		2.5 seconds
59	-	61	N/A		2.5 seconds
62	-	64	High Speed Mode On (700x Only)	Enables High Speed Mode	2.5 seconds
65	-	67	High Speed Mode Off (700x Only)	Disables High Speed Mode	2.5 seconds
68	-	70	Constant Output	Enables Constant Output	2.5 seconds
71	-	73	Maximum Output	Enables Maximum Output	2.5 seconds
74	-	76	Studio Mode ON	Enables Studio Mode	2.5 seconds
77	-	79	Studio Mode OFF	Disables Studio Mode	2.5 seconds
80	-	82	N/A		
83	-	85	N/A		
86	-	88	N/A		
89	-	91	N/A		
92	-	94	N/A		
95	-	97	N/A		
98	-	100	Dim curve Linear	Dim curve Linear	2.5 seconds
101	-	103	Dim curve Exponential	Dim curve Exponential	2.5 seconds
104	-	106	Dim curve Logarithmic	Dim curve Logarithmic	2.5 seconds
107	-	109	Dim curve S-Curve	Dim curve S-Curve	2.5 seconds
110	-	172	N/A		2.5 seconds
173	-	249	Reserved		2.5 seconds
250	-	252	Turn On Control Channel	Defaults to On	2.5 seconds
253	-	255	Turn off Control Channel	Commands sent on the DMX Control Channel will be ignored.	2.5 seconds

DMX FX Parameters

FX Parameter: Paparazzi

Channel	Function	Value	Percent	Description	Default % / DMX
FX					
+1	Crossfade	0-255	0-100%	CCT to FX	0%
+2	Trigger	0 - 69	0 - 27	Trigger / Loop	0%
		70 - 255	28 - 100	Stop	
+3	FX Selection	See Table Above			0
+4	Frequency	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
+5	Variable	N/A	N/A	N/A	

FX Parameter: Fireworks

Channel	Function	Value	Percent	Description	Default % / DMX
FX					
+1	Crossfade	0-255	0-100%	CCT to FX	0%
+2	Trigger	0 - 69	0 - 27	Trigger / Loop	0%
		70 - 255	28 - 100	Stop	
+3	FX Selection	See Table Above			0
+4	Frequency	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
+5	Variable	0 - 9	0 - 4	CCT	0% / 0
		10 - 19	5 - 8	Hue	
		20 - 29	9 - 12	CCT+ Hue	
		30 - 255	13 - 100	Reserved	

FX Parameter: Faulty bulb

Channel	Function	Value	Percent	Description	Default % / DMX
FX					
+1	Crossfade	0-255	0-100%	CCT to FX	0%
+2	Trigger	0 - 69	0 - 27	Trigger / Loop	0%
		70 - 255	28 - 100	Stop	
+3	FX Selection	See Table Above			0
+4	Frequency	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
+5	Variable	0 - 9	0 - 4	CCT	0% / 0
		10 - 19	5 - 8	Hue	
		20 - 29	9 - 12	CCT+ Hue	
		30 - 255	13 - 100	Reserved	

FX Parameter: Lightning

Channel	Function	Value	Percent	Description	Default % / DMX
FX					
+1	Crossfade	0-255	0-100%	CCT to FX	0%
+2	Trigger	0 - 9	0 - 4	Loop	0%
		10 - 69	5 - 27	Trigger / Run Once / Loop	
		70 - 255	28 - 100	Stop	
+3	FX Selection	See Table Above			0
+4	Frequency	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
+5	Variable	N/A	N/A	N/A	

FX Parameter: TV

Channel	Function	Value	Percent	Description	Default % / DMX
FX					
+1	Crossfade	0-255	0-100%	CCT to FX	0%
+2	Trigger	0 - 69	0 - 27	Trigger / Loop	0%
		70 - 255	28 - 100	Stop	
+3	FX Selection	See Table Above			0
+4	Frequency	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
+5	Variable	0 - 9	0 - 4	CCT	0% / 0
		10 - 19	5 - 8	Hue	
		20 - 29	9 - 12	CCT+ Hue	
		30 - 255	13 - 100	Reserved	

FX Parameter: Pulsing

Channel	Function	Value	Percent	Description	Default % / DMX
FX					
+1	Crossfade	0-255	0-100%	CCT to FX	0%
+2	Trigger	0 - 69	0 - 27	Trigger / Loop	0%
		70 - 255	28 - 100	Stop	
+3	FX Selection	See Table Above			0
+4	Frequency /	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
+5	Variable	N/A	N/A	N/A	

FX Parameter: Strobe

Channel	Function	Value	Percent	Description	Default % / DMX
FX					
+1	Crossfade	0-255	0-100%	CCT to FX	0%
+2	Trigger	0 - 69	0 - 27	Trigger / Loop	0%
		70 - 255	28 - 100	Stop	
+3	FX Selection	See Table Above			0
+4	Frequency /	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
+5	Variable	N/A	N/A	N/A	

FX Parameter: Explosion

Channel	Function	Value	Percent	Description	Default % / DMX
FX					
+1	Crossfade	0-255	0-100%	CCT to FX	0%
+2	Trigger	0 - 69	0 - 27	Trigger / Run Once	0%
		70 - 255	28 - 100	Stop	
+3	FX Selection	See Table Above			0
+4	Frequency /	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
+5	Variable	N/A	N/A	N/A	

FX Parameter: Fire

Channel	Function	Value	Percent	Description	Default % / DMX
FX					
+1	Crossfade	0-255	0-100%	CCT to FX	0%
+2	Trigger	0 - 69	0 - 27	Trigger / Loop	0%
		70 - 255	28 - 100	Stop	
+3	FX Selection	See Table Above			0
+4	Frequency	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
+5	Variable	0 - 9	0 - 4	Warm	0% / 0
		10 - 19	5 - 8	Natural	
		20 - 29	9 - 12	Cool	
		30 - 255	13 - 100	Reserved	