



STORM XT52

DMX Profile Specification 1.2

Controller Firmware V1.6

Table of Contents

DMX Profile Overview for Aputure OS II	4
Control Channel Profiles	4
Detailed Breakdown of DMX Channels	4
No Effect Ranges	5
DMX Profiles with Motorized Accessories	5
DMX Profiles without Motorized Accessories	6
Profile 1: CCT+ - 8 Bit (3 ch.)	6
Profile 2: CCT+ - 16 Bit (6 ch.)	6
Profile 3: CCT+ Control - 8 Bit (6 ch.)	7
Profile 4: CCT+ Control - 16 Bit (9 ch.)	8
Profile 5: CCT+ Control & FX - 8 Bit (10 ch.)	9
Profile 6: CCT+ Control & FX - 16 Bit (13 ch.)	11
Profile 7: xy - 8 Bit (3 ch.)	13
Profile 8: xy - 16 Bit (6 ch.)	13
Profile 9: xy Control - 8 Bit (6 ch.)	14
Profile 10: xy Control - 16 Bit (9 ch.)	15
Profile 11: xy Control & FX - 8 Bit (10 ch.)	16
Profile 12: xy Control & FX - 16 Bit (13 ch.)	18
Profile 13: CCT & xy - 8 Bit (6 ch.)	20
Profile 14: CCT & xy - 16 Bit (12 ch.)	20
Profile 15: CCT & xy + Control - 8 Bit (9 ch.)	20
Profile 16: CCT & xy + Control - 16 Bit (15 ch.)	22
Profile 17: Limited CCT & RGB - 8 Bit (7 ch.)	23
Profile 18: Limited CCT & RGB - 16 Bit (14 ch.)	24
Profile 19: Limited CCT & RGB + Control - 8 Bit (10 ch.)	25
Profile 20: Limited CCT & RGB + Control - 16 Bit (17 ch.)	26
Profile 21: Limited HSIC+ - 8 Bit (5 ch.)	26
Profile 22: Limited HSIC+ - 16 Bit (10 ch.)	27
Profile 23: Limited HSIC+ Control - 8 Bit (8 ch.)	28
Profile 24: Limited HSIC+ Control - 16 Bit (13 ch.)	29
Profile 25: RGB - 8 Bit (3 ch.)	29
Profile 26: RGB 16 Bit (6 ch.)	30
Profile 27: RGB + Control - 8 Bit (6 ch.)	30
Profile 28: RGB + Control - 16 Bit (9 ch.)	31
Profile 29: RGBA - 8 Bit (4 ch.)	32
Profile 30: RGBA - 16 Bit (8 ch.)	32
Profile 31: RGBA + Control - 8 Bit (7 ch.)	32
Profile 32: RGBA + Control - 16 Bit (11 ch.)	33
DMX Profiles with Motorized Accessories	34
Profile 101: CCT+ & Acc - 8 Bit (4 ch.)	34
Profile 102: CCT+ & Acc - 16 Bit (8 ch.)	34

Profile 103: CCT+ Control & Acc - 8 Bit (7 ch.)	35
Profile 104: CCT+ Control & Acc - 16 Bit (11 ch.)	36
Profile 105: CCT+ Control, Acc & FX - 8 Bit (11 ch.)	37
Profile 106: CCT+ Control, Acc & FX - 16 Bit (15 ch.)	39
Profile 107: xy & Acc - 8 Bit (4 ch.)	41
Profile 108: xy & Acc - 16 Bit (8 ch.)	41
Profile 109: xy Control & Acc - 8 Bit (7 ch.)	42
Profile 110: xy Control & Acc- 16 Bit (11 ch.)	43
Profile 111: xy Control, Acc & FX - 8 Bit (11 ch.)	44
Profile 112: xy Control, Acc & FX - 16 Bit (15 ch.)	46
Profile 113: CCT & xy & Acc - 8 Bit (7 ch.)	48
Profile 114: CCT & xy & Acc - 16 Bit (14 ch.)	49
Profile 115: CCT & xy + Control & Acc- 8 Bit (10 ch.)	49
Profile 116: CCT & xy + Control & Acc - 16 Bit (17 ch.)	51
Profile 118: Limited CCT & RGB & Acc - 16 Bit (16 ch.)	53
Profile 119: Limited CCT & RGB + Control & Acc - 8 Bit (11 ch.)	54
Profile 120: Limited CCT & RGB + Control & Acc - 16 Bit (19 ch.)	55
Profile 121: Limited HSIC+ & Acc- 8 Bit (6 ch.)	56
Profile 122: Limited HSIC+ & Acc- 16 Bit (12 ch.)	57
Profile 123: Limited HSIC+ Control & Acc - 8 Bit (9 ch.)	58
Profile 124: Limited HSIC+ Control & Acc - 16 Bit (15 ch.)	59
Profile 125: RGB & Acc - 8 Bit (4 ch.)	60
Profile 126: RGB - 16 Bit (8 ch.)	60
Profile 127: RGB + Control & Acc - 8 Bit (7 ch.)	61
Profile 128: RGB + Control & Acc - 16 Bit (13 ch.)	62
Profile 129: RGBA & Acc - 8 Bit (5 ch.)	63
Profile 130: RGBA & Acc - 16 Bit (10 ch.)	63
Profile 131: RGBA + Control & Acc - 8 Bit (8 ch.)	64
Profile 132: RGBA + Control & Acc - 16 Bit (13 ch.)	65
CCT Quick Chart	66
DMX Control Channel Chart	67

DMX Profile Overview for Aputure OS II

With the release of the Storm 1200X, Aputure is launching OS II. OS II features the same menu structure and experience, and DMX Profile Structure between Aputure products.

Control Channel Profiles

Profiles labeled “+Control” include three extra channels (Strobe, Control, and Fan). These profiles are ideal for users seeking advanced control methods.

OS II introduces DMX profiles with three additional control channels, depending on the product:

1. **Strobe Channel:** Enables strobing in any color.
2. **Control Channel:** Allows remote execution of light setting commands via a dedicated DMX channel.
3. **Fan Channel:** Adjusts the fan speed or behavior if the product is equipped with a fan.

Detailed Breakdown of DMX Channels

Strobe Channel:

The Strobe Channel enables strobe effects in any available color configuration, depending on the fixture's color mixing capabilities.

- **Example – Strobe a 10000K Color**
In **Profile 3**, set CCT (**Channel 2**) to 10,000K / 255. Set Strobe (**Channel 4**) to Rate of 25Hz / 255. The light be at Max Strobe at 10,000K.

Control Channel:

The Control Channel allows remote execution of fixture settings via predefined DMX values. To apply a command, assign the specified value to the Control Channel for 2.5 seconds, then reset it to 0. The fixture will issue a brief confirmation flash (red) upon successful execution.

- **Example – Turning DMX Smoothing Off:**
In **Profile 3**, set Control Channel (**Channel 5**) to **Value 27** for 2.5 seconds, then reset it to 0. The fixture will flash red at 20% brightness to indicate that DMX Smoothing has been disabled.
- **Example – Enabling DMX Smoothing:**
To enable DMX Smoothing in **Profile 3**, set **Channel 5** to **Value 30** for 2.5 seconds, then reset to 0. The red flash at 20% brightness confirms the change.

Control Channel Signal Confirmation:

In cases where the confirmation flash is undesirable, such as when modifying multiple fixtures in enclosed spaces, the Signal Confirmation can be disabled by setting the Control Channel to **Value 15**, then back to 0. By default, the Signal Confirmation is enabled.

Fan Channel:

The Fan Channel allows direct control over fan speed or behavior via DMX. Set a constant value to maintain a specific fan state, and modify the value as needed to adjust fan performance.

In the System settings, the Fan mode must be set to "DMX Controlled"

- **Example – Setting the fan to Max**

In **Profile 3**, set the Fan Channel (**Channel 6**) to **Value 45**. The fan channel must be saved at the value. When changing the value in a cue, it can be used to cut the fan during takes.

No Effect Ranges

In some DMX profiles, you may encounter a "No Effect" range at the beginning of a channel. This range is typically meant for slider boards, ensuring that when the slider is at 0, no effect is applied. These ranges should not be patched into lighting consoles, as they serve only to prevent unintended changes when the control is idle.

Channel	Function	Value	Percent	Description
X	±Green	0 - 255	0 - 100	-G to 0G to +G
		0 - 10	0 - 4	No Effect*
		11-20	5 - 8	Full Minus Green
		21 - 119	9 - 47	-99% - -1%
		120 - 145	48 - 57	0% Neutral
		146 - 244	58 - 96	1% - 99%
		245 - 255	97 - 100	Full Plus Green

DMX Profiles with Motorized Accessories

DMX Profiles 101–132 include support for the Motorized Fresnel. These profiles are functionally identical to DMX Profiles 1–32 but add additional DMX channels at the end of each profile to control the Motorized Fresnel. This structure ensures compatibility while providing extended control for fixtures equipped with motorized hardware.

DMX Profiles without Motorized Accessories

Profile 1: CCT+ - 8 Bit (3 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 133
		0 - 10	0 - 4	No Effect*	
		11-20	5 - 8	Full Minus Green	
		21 - 119	9 - 47	-99% - -1%	
		120 - 145	48 - 57	0% Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	Full Plus Green	

*Do not patch "No Effect" range into consoles

Profile 2: CCT+ - 16 Bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 34079
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5 - 8	Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0% Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	Full Plus Green	

*Do not patch "No Effect" range into consoles

Profile 3: CCT+ Control - 8 Bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 133
		0 - 10	0 - 4	No Effect*	
		11-20	5 - 8	Full Minus Green	
		21 - 119	9 - 47	-99% - -1%	
		120 - 145	48 - 57	0% Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	Full Plus Green	
Control Channels					
4	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
5	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
6	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 4: CCT+ Control - 16 Bit (9 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 34079
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0% Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	Full Plus Green	
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
9	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 5: CCT+ Control & FX - 8 Bit (10 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K to 10000K	3200K / 24
3	±Green	0 - 255 0 - 10 11-20 21 - 119 120 - 145 146 - 244 245 - 255	0 - 100 0 - 4 5 - 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 133
FX					
4	Crossfade	0-255	0-100%	Crossfade from Static Color to FX	0%
5	Lightning	0 - 9	0 - 4	Loop	0 / Loop
		10 - 69	5 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Explosion	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Other Effects	0 - 69	0 - 27	Trigger	
6	Effect Selection	70 - 225	28 - 100	Stop	0
		0 - 9	0 - 4	Paparazzi	
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
		90 - 255	37 - 100	Reserved	
7	Frequency	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	

		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
Control Channels					
8	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
9	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
10	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 6: CCT+ Control & FX - 16 Bit (13 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 255	0 - 100	2500K to 10000K	3200K / 6117
5 / 6	±Green	0 - 65535 0 - 2621 2622 - 5243 5244 - 30146 30147 - 37355 37356 - 62914 62915 - 65535	0 - 100 0 - 4 5 - 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 34079
FX					
7	Crossfade	0-255	0-100%	Crossfade from Static Color to FX	0%
8	Lightning	0 - 9	0 - 4	Loop	0
		10 - 69	5 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Explosion	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Other Effects	0 - 69	0 - 27	Trigger	
9	Effect Selection	70 - 225	28 - 100	Stop	0
		0 - 9	0 - 4	Paparazzi	
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
10	Frequency	90 - 255	37 - 100	Reserved	0
		0 - 19	0 - 7	1	
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	

		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
Control Channels					
11	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
12	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
13	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 7: xy - 8 Bit (3 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.4234 / 136)
3	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.3989 / 125)

The xy range of the light is 0.1550y to 0.6815y and 0.3000x to 0.5500x. The Profile is created out of the 0 to 0.8 range.

Profile 8: xy - 16 Bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.4234 / 34684)
5 / 6	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.3989 / 32686)

The xy range of the light is 0.1550y to 0.6815y and 0.3000x to 0.5500x. The Profile is created out of the 0 to 0.8 range.

Profile 9: xy Control - 8 Bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.4234 / 136)
3	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.3989 / 125)
Control Channels					
4	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
5	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / 0
6	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 10: xy Control - 16 Bit (9 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.4234 / 34684)
5 / 6	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.3989 / 32686)
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / 0
9	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 11: xy Control & FX - 8 Bit (10 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.4234 / 136)
3	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.3989 / 125)
FX					
4	Crossfade	0-255	0-100%	Crossfade from Static Color to FX	100%
5	Lightning	0 - 9	0 - 4	Loop	
		10 - 69	5 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Explosion	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Other Effects	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	6	Effect Selection	0 - 9	0 - 4	Paparazzi
10 - 19			5 - 8	Fireworks	
20 - 29			9 - 12	Faulty bulb	
30 - 39			13 - 16	Lightning	
40 - 49			17 - 20	TV	
50 - 59			21 - 24	Pulsing	
60 - 69			25 - 28	Strobe	
70 - 79			29 - 32	Explosion	
80 - 89			33 - 36	Fire	
90 - 255			37 - 100	Reserved	
7	Frequency	0 - 19	0 - 7	1	
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
		Control Channels			
8	Strobe	0 - 13	0 - 5	Off	0 / Off

		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
9	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / 0
10	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 12: xy Control & FX - 16 Bit (13 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.4234 / 34684)
5 / 6	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.3989 / 32686)
FX					
7	Crossfade	0-255	0-100%	Crossfade from Static Color to FX	0%
8	Lightning	0 - 9	0 - 4	Loop	
		10 - 69	5 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Explosion	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Other Effects	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
9	Effect Selection	0 - 9	0 - 4	Paparazzi	
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
		90 - 255	37 - 100	Reserved	
10	Frequency	0 - 19	0 - 7	1	
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
Control Channels					
11	Strobe	0 - 13	0 - 5	Off	0 / Off

		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
12	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
13	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 13: CCT & xy - 8 Bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0-100	CCT to xy	0
5	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.3145 / 101)
6	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.3178 / 102)
				*Do not patch "No Effect" range into consoles	

Profile 14: CCT & xy - 16 Bit (12 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7 / 8	Crossfade	0 - 65535	0-100	CCTRGB to xy	0
9 / 10	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.3139 / 25715)
11 / 12	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.3240 / 26542)
				*Do not patch "No Effect" range into consoles	

Profile 15: CCT & xy + Control - 8 Bit (9 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0-100	CCTRGB to xy	0
5	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.3145 / 101)
6	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.3178 / 102)
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
9	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
				*Do not patch “No Effect” range into consoles	

Profile 16: CCT & xy + Control - 16 Bit (15 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7 / 8	Crossfade	0 - 65535	0-100	CCTRGB to xy	0
9 / 10	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.3139 / 25715)
11 / 12	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.3240 / 26542)
Control Channels					
13	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
14	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
15	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
				*Do not patch “No Effect” range into consoles	

Profile 17: Limited CCT & RGB - 8 Bit (7 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0-100	White Light to RGB	0
5	Red	0 - 255	0-100	Red Intensity	100% / 255
6	Green	0 - 255	0-100	Green Intensity	100% / 255
7	Blue	0 - 255	0-100	Blue Intensity	100% / 255
				*Do not patch "No Effect" range into consoles	

Profile 18: Limited CCT & RGB - 16 Bit (14 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7/8	Crossfade	0 - 65535	0-100	White Light to RGB	0
9/10	Red	0 - 65535	0-100	Red Intensity	100% / 65535
11/12	Green	0 - 65535	0-100	Green Intensity	100% / 65535
13/14	Blue	0 - 65535	0-100	Blue Intensity	100% / 65535
				*Do not patch "No Effect" range into consoles	

Profile 19: Limited CCT & RGB + Control - 8 Bit (10 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0-100	White Light to RGB	0
5	Red	0 - 255	0-100	Red Intensity	100% / 255
6	Green	0 - 255	0-100	Green Intensity	100% / 255
7	Blue	0 - 255	0-100	Blue Intensity	100% / 255
Control Channels					
8	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
9	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
10	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
				*Do not patch “No Effect” range into consoles	

Profile 20: Limited CCT & RGB + Control - 16 Bit (17 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7/8	Crossfade	0 - 65535	0-100	White Light to RGB	0
9/10	Red	0 - 65535	0-100	Red Intensity	100% / 65535
11/12	Green	0 - 65535	0-100	Green Intensity	100% / 65535
13/14	Blue	0 - 65535	0-100	Blue Intensity	100% / 65535
Control Channels					
15	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
16	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
17	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
				*Do not patch “No Effect” range into consoles	

Profile 21: Limited HSIC+ - 8 Bit (5 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Hue	0 - 255	0 to 359.9°		0° / 0
5	Saturation	0 - 255	0 - 100%	White Light to RGB	0% / 0
				*Do not patch "No Effect" range into consoles	

Profile 22: Limited HSIC+ - 16 Bit (10 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5/6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7/8	Hue	0 - 65535	0 to 359.9°		0° / 0
9/10	Saturation	0 - 65535	0 - 100%	White Light to RGB	0% / 0
				*Do not patch "No Effect" range into consoles	

Profile 23: Limited HSIC+ Control - 8 Bit (8 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Hue	0 - 255	0 to 359.9°		0° / 0
5	Saturation	0 - 255	0 - 100%	White Light to RGB	0% / 0
Control Channels					
6	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
7	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
8	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
				*Do not patch “No Effect” range into consoles	

Profile 24: Limited HSIC+ Control - 16 Bit (13 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5/6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7/8	Hue	0 - 65535	0 to 359.9°		0° / 0
9/10	Saturation	0 - 65535	0 - 100%	White Light to RGB	0% / 0
Control Channels					
11	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
12	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
13	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
				*Do not patch “No Effect” range into consoles	

Profile 25: RGB - 8 Bit (3 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1	Red	0 - 255	0-100	Red Intensity	0% / 0
2	Green	0 - 255	0-100	Green Intensity	0% / 0
3	Blue	0 - 255	0-100	Blue Intensity	0% / 0

Profile 26: RGB 16 Bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1 / 2	Red	0 - 65535	0-100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0-100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0-100	Blue Intensity	0% / 0

Profile 27: RGB + Control - 8 Bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1	Red	0 - 255	0-100	Red Intensity	0% / 0
2	Green	0 - 255	0-100	Green Intensity	0% / 0
3	Blue	0 - 255	0-100	Blue Intensity	0% / 0
Control Channels					
4	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
5	Control Channel	0 - 255	0-100	SEE CONTROL CHANNEL CHART	0 / Off
6	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

Profile 28: RGB + Control - 16 Bit (9 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1 / 2	Red	0 - 65535	0-100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0-100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0-100	Blue Intensity	0% / 0
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0-100	SEE CONTROL CHANNEL CHART	0 / Off
9	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

Profile 29: RGBA - 8 Bit (4 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Red	0 - 255	0-100	Red Intensity	0% / 0
2	Green	0 - 255	0-100	Green Intensity	0% / 0
3	Blue	0 - 255	0-100	Blue Intensity	0% / 0
4	Amber	0 - 255	0-100	Amber Intensity	0% / 0

Profile 30: RGBA - 16 Bit (8 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Red	0 - 65535	0-100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0-100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0-100	Blue Intensity	0% / 0
7 / 8	Amber	0 - 65535	0-100	Amber Intensity	0% / 0

Profile 31: RGBA + Control - 8 Bit (7 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Red	0 - 255	0-100	Red Intensity	0% / 0
2	Green	0 - 255	0-100	Green Intensity	0% / 0
3	Blue	0 - 255	0-100	Blue Intensity	0% / 0
4	Amber	0 - 255	0-100	Amber Intensity	0% / 0
Control Channels					
5	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
6	Control Channel	0 - 255	0-100	SEE CONTROL CHANNEL CHART	0 / Off
7	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

Profile 32: RGBA + Control - 16 Bit (11 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Red	0 - 65535	0-100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0-100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0-100	Blue Intensity	0% / 0
7 / 8	Amber	0 - 65535	0-100	Amber Intensity	0% / 0
Control Channels					
9	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
10	Control Channel	0 - 255	0-100	SEE CONTROL CHANNEL CHART	0 / Off
11	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	

DMX Profiles with Motorized Accessories

Profile 101: CCT+ & Acc - 8 Bit (4 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255 0 - 10 11-20 21 - 119 120 - 145 146 - 244 245 - 255	0 - 100 0 - 4 5 - 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 133
Accessories					
4	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0

*Do not patch "No Effect" range into consoles

*If accessory is not used, channel is 0 Value

Profile 102: CCT+ & Acc - 16 Bit (8 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535 0 - 2621 2622 - 5243 5244 - 30146 30147 - 37355 37356 - 62914 62915 - 65535	0 - 100 0 - 4 5- 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 34079
Accessories					
7 / 8	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0

*Do not patch "No Effect" range into consoles

Profile 103: CCT+ Control & Acc - 8 Bit (7 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255 0 - 10 11-20 21 - 119 120 - 145 146 - 244 245 - 255	0 - 100 0 - 4 5 - 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 133
Control Channels					
4	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
5	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
6	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
7	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 104: CCT+ Control & Acc - 16 Bit (11 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535 0 - 2621 2622 - 5243 5244 - 30146 30147 - 37355 37356 - 62914 62915 - 65535	0 - 100 0 - 4 5- 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 34079
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
9	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
10 / 11	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0

Profile 105: CCT+ Control, Acc & FX - 8 Bit (11 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K to 10000K	3200K / 24
3	±Green	0 - 255 0 - 10 11-20 21 - 119 120 - 145 146 - 244 245 - 255	0 - 100 0 - 4 5 - 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 133
FX					
4	Crossfade	0-255	0-100%	Crossfade from Static Color to FX	0%
5	Lightning	0 - 9	0 - 4	Loop	0 / Loop
		10 - 69	5 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Explosion	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Other Effects	0 - 69	0 - 27	Trigger	
6	Effect Selection	70 - 225	28 - 100	Stop	0
		0 - 9	0 - 4	Paparazzi	
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
7	Frequency	90 - 255	37 - 100	Reserved	0
		0 - 19	0 - 7	1	
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	

		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
Control Channels					
8	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
9	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
10	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
Accessories					
11	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 106: CCT+ Control, Acc & FX - 16 Bit (15 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
3 / 4	CCT	0 - 255	0 - 100	2500K to 10000K	3200K / 6117
5 / 6	±Green	0 - 65535 0 - 2621 2622 - 5243 5244 - 30146 30147 - 37355 37356 - 62914 62915 - 65535	0 - 100 0 - 4 5 - 8 9 - 47 48 - 57 58 - 96 97 - 100	-G to 0G to +G No Effect* Full Minus Green -99% - -1% 0% Neutral 1% - 99% Full Plus Green	Neutral / 34079
FX					
7	Crossfade	0-255	0-100%	Crossfade from Static Color to FX	0%
8	Lightning	0 - 9	0 - 4	Loop	0
		10 - 69	5 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Explosion	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Other Effects	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
9	Effect Selection	0 - 9	0 - 4	Paparazzi	0
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
		90 - 255	37 - 100	Reserved	
10	Frequency	0 - 19	0 - 7	1	0
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	

		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
Control Channels					
11	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
12	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
13	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
14 / 15	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 107: xy & Acc - 8 Bit (4 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.4234 / 136)
3	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.3989 / 125)
Accessories					
4	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0

The xy range of the light is 0.1550y to 0.6815y and 0.3000x to 0.5500x. The Profile is created out of the 0 to 0.8 range.

Profile 108: xy & Acc - 16 Bit (8 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.4234 / 34684)
5 / 6	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.3989 / 32686)
Accessories					
7 / 8	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0

The xy range of the light is 0.1550y to 0.6815y and 0.3000x to 0.5500x. The Profile is created out of the 0 to 0.8 range.

Profile 109: xy Control & Acc - 8 Bit (7 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.4234 / 136)
3	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.3989 / 125)
Control Channels					
4	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
5	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / 0
6	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
7	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 110: xy Control & Acc- 16 Bit (11 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.4234 / 34684)
5 / 6	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.3989 / 32686)
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / 0
9	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
10 / 11	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 111: xy Control, Acc & FX - 8 Bit (11 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.4234 / 136)
3	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (0.3989 / 125)
FX					
4	Crossfade	0-255	0-100%	Crossfade from Static Color to FX	100%
5	Lightning	0 - 9	0 - 4	Loop	
		10 - 69	5 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Explosion	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Other Effects	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
6	Effect Selection	0 - 9	0 - 4	Paparazzi	
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
		90 - 255	37 - 100	Reserved	
7	Frequency	0 - 19	0 - 7	1	
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
Control Channels					
8	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	

		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
9	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / 0
10	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
11	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 112: xy Control, Acc & FX - 16 Bit (15 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 - 100%	0% / 0
3 / 4	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.4234 / 34684)
5 / 6	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (0.3989 / 32686)
FX					
7	Crossfade	0-255	0-100%	Crossfade from Static Color to FX	0%
8	Lightning	0 - 9	0 - 4	Loop	
		10 - 69	5 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Explosion	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
	Other Effects	0 - 69	0 - 27	Trigger	
		70 - 225	28 - 100	Stop	
9	Effect Selection	0 - 9	0 - 4	Paparazzi	
		10 - 19	5 - 8	Fireworks	
		20 - 29	9 - 12	Faulty bulb	
		30 - 39	13 - 16	Lightning	
		40 - 49	17 - 20	TV	
		50 - 59	21 - 24	Pulsing	
		60 - 69	25 - 28	Strobe	
		70 - 79	29 - 32	Explosion	
		80 - 89	33 - 36	Fire	
		90 - 255	37 - 100	Reserved	
10	Frequency	0 - 19	0 - 7	1	
		20 - 39	8 - 15	2	
		40 - 59	16 - 23	3	
		60 - 79	24 - 31	4	
		80 - 99	32 - 39	5	
		100 - 119	40 - 47	6	
		120 - 139	48 - 55	7	
		140 - 159	56 - 63	8	
		160 - 179	64 - 71	9	
		180 - 199	72 - 79	10	
		200 - 219	80 - 87	Random	
		220 - 255	88 - 100	Reserved	
Control Channels					
11	Strobe	0 - 13	0 - 5	Off	0 / Off

		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
12	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
13	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
14 / 15	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0

* Do not patch "No Effect" range into consoles

When set to DMX Control In Settings

Profile 113: CCT & xy & Acc - 8 Bit (7 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0-100	CCT to xy	0
5	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.3145 / 101)
6	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.3178 / 102)
Accessories					
7	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0
				*Do not patch "No Effect" range into consoles	

Profile 114: CCT & xy & Acc - 16 Bit (14 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7 / 8	Crossfade	0 - 65535	0-100	CCTRGB to xy	0
9 / 10	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.3139 / 25715)
11 / 12	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.3240 / 26542)
Accessories					
13 / 14	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0
				*Do not patch "No Effect" range into consoles	

Profile 115: CCT & xy + Control & Acc- 8 Bit (10 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0-100	CCTRGB to xy	0
5	x Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.3145 / 101)
6	y Coordinate	0 - 255	0 - 100	0 - 0.8	3200K (.3178 / 102)
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
9	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
10	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0
				*Do not patch “No Effect” range into consoles	

Profile 116: CCT & xy + Control & Acc - 16 Bit (17 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7 / 8	Crossfade	0 - 65535	0-100	CCTRGB to xy	0
9 / 10	x Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.3139 / 25715)
11 / 12	y Coordinate	0 - 65535	0 - 100	0 - 0.8	3200K (.3240 / 26542)
Control Channels					
13	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
14	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
15	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
16 / 17	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0
				*Do not patch “No Effect” range into consoles	

Profile 117: Limited CCT & RGB & Acc - 8 Bit (8 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0-100	White Light to RGB	0
5	Red	0 - 255	0-100	Red Intensity	100% / 255
6	Green	0 - 255	0-100	Green Intensity	100% / 255
7	Blue	0 - 255	0-100	Blue Intensity	100% / 255
Accessories					
8	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0
				*Do not patch "No Effect" range into consoles	

Profile 118: Limited CCT & RGB & Acc - 16 Bit (16 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7/8	Crossfade	0 - 65535	0-100	White Light to RGB	0
9/10	Red	0 - 65535	0-100	Red Intensity	100% / 65535
11/12	Green	0 - 65535	0-100	Green Intensity	100% / 65535
13/14	Blue	0 - 65535	0-100	Blue Intensity	100% / 65535
Accessories					
15 / 16	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0
				*Do not patch "No Effect" range into consoles	

Profile 119: Limited CCT & RGB + Control & Acc - 8 Bit (11 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Crossfade	0 - 255	0-100	White Light to RGB	0
5	Red	0 - 255	0-100	Red Intensity	100% / 255
6	Green	0 - 255	0-100	Green Intensity	100% / 255
7	Blue	0 - 255	0-100	Blue Intensity	100% / 255
Control Channels					
8	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
9	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
10	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
11	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0
				*Do not patch “No Effect” range into consoles	

Profile 120: Limited CCT & RGB + Control & Acc - 16 Bit (19 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 65535	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5 / 6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7/8	Crossfade	0 - 65535	0-100	White Light to RGB	0
9/10	Red	0 - 65535	0-100	Red Intensity	100% / 65535
11/12	Green	0 - 65535	0-100	Green Intensity	100% / 65535
13/14	Blue	0 - 65535	0-100	Blue Intensity	100% / 65535
Control Channels					
15	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
16	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
17	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
18 / 19	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0
				*Do not patch “No Effect” range into consoles	

Profile 121: Limited HSIC+ & Acc- 8 Bit (6 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Hue	0 - 255	0 to 359.9°		0° / 0
5	Saturation	0 - 255	0 - 100%	White Light to RGB	0% / 0
Accessories					
6	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0
				*Do not patch "No Effect" range into consoles	

Profile 122: Limited HSIC+ & Acc- 16 Bit (12 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5/6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7/8	Hue	0 - 65535	0 to 359.9°		0° / 0
9/10	Saturation	0 - 65535	0 - 100%	White Light to RGB	0% / 0
Accessories					
11 / 12	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0
				*Do not patch "No Effect" range into consoles	

Profile 123: Limited HSIC+ Control & Acc - 8 Bit (9 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
2	CCT	0 - 255	0 - 100	2500K- 10000K	3200K / 24
3	±Green	0 - 255	0 - 100	-G to 0G to +G	Neutral / 50% / 133
		0 - 10	0 - 4	No Effect*	
		11 - 20	5- 8	-100 / Full Minus Green	
		21 - 119	9 - 46	-99% - -1%	
		120 - 145	47 - 57	0 % / Neutral	
		146 - 244	58 - 96	1% - 99%	
		245 - 255	97 - 100	100% / Full Plus Green	
4	Hue	0 - 255	0 to 359.9°		0° / 0
5	Saturation	0 - 255	0 - 100%	White Light to RGB	0% / 0
Control Channels					
6	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
7	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
8	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
9	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0
				*Do not patch “No Effect” range into consoles	

Profile 124: Limited HSIC+ Control & Acc - 16 Bit (15 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Intensity	0 - 255	0 - 100	0 0 - 100%	0% / 0
3 / 4	CCT	0 - 65535	0 - 100	2500K- 10000K	3200K / 6117
5/6	±Green	0 - 65535	0 - 100	-G to 0G to +G	Neutral / 50% / 33918
		0 - 2621	0 - 4	No Effect*	
		2622 - 5243	5- 8	-100 / Full Minus Green	
		5244 - 30146	9 - 47	-99% - -1%	
		30147 - 37355	48 - 57	0 % / Neutral	
		37356 - 62914	58 - 96	1% - 99%	
		62915 - 65535	97 - 100	100% / Full Plus Green	
7/8	Hue	0 - 65535	0 to 359.9°		0° / 0
9/10	Saturation	0 - 65535	0 - 100%	White Light to RGB	0% / 0
Control Channels					
11	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
12	Control Channel	0 - 255	0-100	See Control Channel Chart	0 / Off
13	Fan Mode#	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
14 / 15	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0
				*Do not patch “No Effect” range into consoles	

Profile 125: RGB & Acc - 8 Bit (4 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1	Red	0 - 255	0-100	Red Intensity	0% / 0
2	Green	0 - 255	0-100	Green Intensity	0% / 0
3	Blue	0 - 255	0-100	Blue Intensity	0% / 0
Accessories					
4	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0

Profile 126: RGB - 16 Bit (8 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1 / 2	Red	0 - 65535	0-100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0-100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0-100	Blue Intensity	0% / 0
Accessories					
7 / 8	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0

Profile 127: RGB + Control & Acc - 8 Bit (7 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1	Red	0 - 255	0-100	Red Intensity	0% / 0
2	Green	0 - 255	0-100	Green Intensity	0% / 0
3	Blue	0 - 255	0-100	Blue Intensity	0% / 0
Control Channels					
4	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
5	Control Channel	0 - 255	0-100	SEE CONTROL CHANNEL CHART	0 / Off
6	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
7	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0

Profile 128: RGB + Control & Acc - 16 Bit (13 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
CCT is Locked at 6500K					
1 / 2	Red	0 - 65535	0-100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0-100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0-100	Blue Intensity	0% / 0
Control Channels					
7	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
8	Control Channel	0 - 255	0-100	SEE CONTROL CHANNEL CHART	0 / Off
9	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
10 / 11	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0

Profile 129: RGBA & Acc - 8 Bit (5 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Red	0 - 255	0-100	Red Intensity	0% / 0
2	Green	0 - 255	0-100	Green Intensity	0% / 0
3	Blue	0 - 255	0-100	Blue Intensity	0% / 0
4	Amber	0 - 255	0-100	Amber Intensity	0% / 0
Accessories					
5	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0

Profile 130: RGBA & Acc - 16 Bit (10 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Red	0 - 65535	0-100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0-100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0-100	Blue Intensity	0% / 0
7 / 8	Amber	0 - 65535	0-100	Amber Intensity	0% / 0
Accessories					
9 / 10	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0

Profile 131: RGBA + Control & Acc - 8 Bit (8 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1	Red	0 - 255	0-100	Red Intensity	0% / 0
2	Green	0 - 255	0-100	Green Intensity	0% / 0
3	Blue	0 - 255	0-100	Blue Intensity	0% / 0
4	Amber	0 - 255	0-100	Amber Intensity	0% / 0
Control Channels					
5	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
6	Control Channel	0 - 255	0-100	SEE CONTROL CHANNEL CHART	0 / Off
7	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
8	Zoom	0 - 255	0 - 100	XX° - XX°	0 / 0

Profile 132: RGBA + Control & Acc - 16 Bit (13 ch.)

Channel	Function	Value	Percent	Description	Default % / DMX
1 / 2	Red	0 - 65535	0-100	Red Intensity	0% / 0
3 / 4	Green	0 - 65535	0-100	Green Intensity	0% / 0
5 / 6	Blue	0 - 65535	0-100	Blue Intensity	0% / 0
7 / 8	Amber	0 - 65535	0-100	Amber Intensity	0% / 0
Control Channels					
9	Strobe	0 - 13	0 - 5	Off	0 / Off
		14 - 128	6 - 50	Random (0.4Hz -> 25Hz)	
		129 - 255	51 - 100	Constant (0.4Hz -> 25Hz)	
10	Control Channel	0 - 255	0-100	SEE CONTROL CHANNEL CHART	0 / Off
11	Fan Mode	0 - 38	0 - 15	Auto/Smart	Auto / 0
		39 - 77	16 - 30	Max	
		78 - 115	31 - 45	Medium	
		116 - 153	46 - 60	Low	
		154 - 191	61 - 75		
		192 - 255	76 - 100	Silent	
Accessories					
12 / 13	Zoom	0 - 65535	0 - 100	XX° - XX°	0 / 0

CCT Quick Chart

CCT	8-bit DMX Value	16-bit DMX Value
2500 K	0	0
3200 K	24	6117
3800 K	44	11360
4300 K	61	15729
4800 K	78	20098
5600 K	106	27088
6500 K	136	34952
7500 K	170	43690
9000 K	221	56797
10000 K	255	66535

DMX Control Channel Chart

The DMX Control Channel of the Profile should be a 0 value and then moved to the specific DMX Value to execute the command. Once executed, the DMX value should be returned to zero.

DMX			FUNCTION	DESCRIPTION	Time to Save
0	-	10	No function	Nothing	2.5 seconds
11	-	13	Signal Flash Enabled	When sending a Control Channel Command, the Light Flashes to confirm received	2.5 seconds
14	-	16	Signal Flash Disabled	When sending a Control Channel Command, the Light will not flash when a command is received.	2.5 seconds
17	-	19	Sidus BT On		2.5 seconds
20	-	22	Sidus BT Off		2.5 seconds
23	-	25	Sidus BT Reset		2.5 seconds
26	-	28	DMX Smoothing: Off	Snap to Intensities	2.5 seconds / Instant On
29	-	31	DMX Smoothing: Smooth	Smooth to Intensities	2.5 seconds / Instant On
32	-	34	DMX Smoothing: Super Smooth	Super Smooth to Intensities	2.5 seconds / Instant On
35	-	37	DMX Smoothing: Feather	Super Smooth from 0-4%, Snaps from 5 to 100%	2.5 seconds / Instant On
38	-	40	CRMX On	Turns wireless CRMX ON	2.5 seconds
41	-	43	CRMX Off	Turns wireless CRMX OFF	2.5 seconds
44	-	46	CRMX Unlink	TX: Unlink all linked fixtures RX: Unlink the fixture from a CRMX transmitter	2.5 seconds
47	-	49	CRMX Link	If set as a CRMX Transmitter, it will send the Link Signal	2.5 seconds
50	-	52	CRMX Mode RX	If set to a CRMX TX, it will change to RX. If it is off, it will remain off.	2.5 seconds

53	-	55	CRMX Mode TX	If set to a CRMX RX, it will change to TX. If it is off, it will remain off.	2.5 seconds
56	-	58	RDM off	Turns off the RDM	2.5 seconds
59	-	61	RDM on	Turns on the RDM	2.5 seconds
62	-	64	High Speed Mode On	if available	2.5 seconds
65	-	67	High Speed Mode Off	if available	2.5 seconds
68	-	70	Constant Output		2.5 seconds
71	-	73	Maximum Output		2.5 seconds
74	-	76	Studio Mode ON		2.5 seconds
77	-	79	Studio Mode OFF		2.5 seconds
80	-	82	Turn On Fan DMX Control Channel		2.5 seconds
83	-	85	Turn Off Fan DMX Control Channel	Sets Fan to Smart	2.5 seconds
86	-	88	N/A		
89	-	91	N/A		
92	-	94	N/A		
95	-	97	N/A		
98	-	100	Dim curve Linear	Dim curve Linear	2.5 seconds
101	-	103	Dim curve Exponential	Dim curve Exponential	2.5 seconds
104	-	106	Dim curve Logarithmic	Dim curve Logarithmic	2.5 seconds
107	-	109	Dim curve S-Curve	Dim curve S-Curve	2.5 seconds
110	-	172	N/A		2.5 seconds
173	-	249	Reserved		2.5 seconds
250	-	252	Turn On Control Channel	Defaults to On	2.5 seconds
253	-	255	Turn off Control Channel	Commands sent on the DMX Control Channel will be ignored.	2.5 seconds