




Aputure Lightning Clamp to Ultra Clamp Adapter Kit


Product Manual

English


Introduction

This adapter kit is designed to retrofit your control box equipped with a Lightning mounting plate to the latest Aputure Ultra mounting structure. When used together with the Aputure Ultra Clamp included in this kit, it enables rapid installation and removal while greatly improving the stability and long-term reliability of the control box's quick-mount system.

Components List



Aputure Ultra Clamp x 1



Aputure Lightning Clamp
to Ultra Clamp Adapter Plate x 1

Operating Instructions

1. Install the Aputure Lightning Clamp to Ultra Clamp adapter Plate.

As shown in the figure below, install the Lightning Clamp to Ultra Clamp Adapter Plate onto the Lightning mounting plate of the control box.




Figure1




Figure2





Figure3*


** Installation Requirements: Please use an H3 Allen wrench to fully tighten the screws to ensure a secure connection. Warning: Insufficient tightening of screws may cause the product to loosen, shift, or fall off.*

2.Install Ultra Clamp

As shown in the figure below, install the control box with the Lightning Clamp to Ultra Clamp Adapter Plate installed onto the Ultra Clamp



Mounting



Detaching

Ultra Clamp specification	Dimension:18.3x11x8.3cm
	Weight:0.92kg
Clamp range (Section)	Square Tube: 2x2 cm to 4x4 cm
	Round Tube: Dia. 3/8"(0.95cm) to Dia. 2.25"(5.72cm)
Lightning Clamp to Ultra Clamp Adapter Plate specification	Dimension: 5.1 x 10.45 x 2.85cm
	Weight: 0.22kg
Compatible products	Storm Series:XT52/700x/400x/1200x/1000c Light Storm Series:1200d Pro/600d Pro/600c Pro II/600x Pro/300x/C120d II/C300d II/600d

Important Safety Instructions

1. Please read and understand all instructions before use.
2. Do not disassemble the product yourself. If damaged, please contact after-sales service.
3. Do not expose the product to high temperatures for extended periods, as this may accelerate aging and deformation.
4. This is a special device; keep it out of reach of children.
5. When used with lamps, localized high temperatures may occur; be careful to avoid burns.
6. Avoid placing the device near flammable or volatile solvents such as alcohol and gasoline.
7. Please use this product according to the instructions in the manual. Improper operation may damage the product.
8. This manual is based on company standards. Changes to product design and specifications are subject to change without notice.

Disclaimer

Please read the Product Manual before usage to ensure that you have fully understood the instructions and can correctly operate the device. After your reading, please keep the Product Manual properly for reference in the future. If you fail to operate the product correctly, you may get injured seriously or harm others seriously, or damage the product and result in your property damage. Your operation of the product will be deemed that you have understood, recognized and accepted all clauses and content of this document. Users undertake to be responsible for their behaviors and the consequences accordingly. Aputure will not be responsible for all losses arising from users' operation of this product not in accordance with the User's Manual.

The Company reserves the right for the final explanation of this document and all documents relating to the product on the premise of compliance with laws and regulations. No further notice will be given in the event of any update, revision or termination. Please access the official website of Aputure for the up-to-date product information.